

User Manual

EXTREME
PPA110A



Safety Precautions

ENGLISH

Fixing and installation of this speaker cabinet must be carried out by qualified personnel following the approved safety standards.

Do not attempt to clean the plastic enclosure with solvents or petrochemical based cleaners.

Do not place objects which are sources of heat on the speaker cabinet such as lighting equipment or smoke machines.

Do not expose the speaker cabinet to direct rain or stand in water. Liquid getting into the box will risk a short circuit and will be hazardous.

Do not stack the speaker cabinet in a manner that could cause injury should a cabinet become dislodge.

Additional precautions for Auto-amplified devices of the series.

Before installation, ensure that the voltage and frequency of power outlet match the power requirements of the loudspeaker.

Disconnect from main power before to make connections in the loudspeaker.

Make sure that the power-cord is never crimped or damaged by sharp edges. Never let the power-cord come into contact with other cables. Only handle the power-cord by the plug.

In case to replace the fuse, it must be changed by identical rate and dimensions.


Attention

Before connecting or operating your new loudspeaker, please study the accompanying instruction manual paying special attention to the operating precautions and wiring procedure.








This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

BACK PANEL AMPLIFIER



1.MP3 player :USB/SD/Bluetooth input and MP3 player

MENU	MP3 Player
MODE	Stop / Detener
	Pause/Play
	Repeat
	Last Music Song
	Next Music Song
	Bluetooth

2.Volume 1 : Control the Volume of Microphone input .

3. Volume 2: Control the Volume of line in

4. Equalizer : to control the tone level of high frequency at range -12dB to + 12dB

5. Equalizer : to control the tone level of low frequency at range -12dB to + 12dB

6. Volume : it controls the volume of MP3

7.Clip LED : it is light up when the applied input signal reaches to distortion , reduce the input level in order to eliminate the distortion .

8. 6.35mm Connector device ,like Mobile

9. Switch for Mic and Line input

10.1/4 Jack for Mic input

11. XLR Connector for Mic input and Line input

12. Balanced RCA connector for devices like CD,Tuner or mixer, etc.

13. XLR output for Mic

14.Power Switch : It allows to switch on / off the unit

15.Main supply inlet : Connect here an IEC main power cable in order to supply the unit .